


## INSTRUCTIONS -BUTTON MAKER 1"



1. Cut out your image.



2. Place the shell part of the pin casing onto the left hand mold.




3. Place the cut image, followed by the mylar cover, on top of the shell.



4. Push the mold set to the right and align with the press.

5. Push the handle down to move the shell to the bottom.

6. Place the bottom (pin) side of the tinplate on to the right hand mold.



7. Push the mold set to the left and align with the press.

8. Press the handle down firmly to set your button.



9. Push the slide rail to the right and remove your finished button.

### Supplies needed to make a button:

- Artwork
- Pin casing (shell, mylar (plastic covering), pin back)

Pin casing kits are available for purchase from the Library for 15 cents. If you want to order a large supply, it must be ordered from [vevor.com](http://vevor.com).